

## Front Sidemarker Installation (cont.)



7. Twist the plug back into the new sidemarker to seal.



8. Place the sidemarker back into the bumper, and tighten the nuts on the rear. Do not overtighten!



9. Put wheel well back into place, and reinstall the screws. Repeat for other side.

### NEED MORE HELP?

Scan the QR code to link to our installation video online!

We've taken the time to test our products on your vehicle. We can guarantee compatibility and fitment the first time. No guessing game! If you need more help with installation, watch our step-by-step video to walk you through the process.

YouTube



Please contact **Diode Dynamics** should you have any questions about the installation process, at **314-205-3033** (9a-5p CST) or **contact@diodedynamics.com**.

Visit [www.diodedynamics.com](http://www.diodedynamics.com) to find more products for any vehicle.

100% SATISFACTION  
GUARANTEE

3 YEAR  
WARRANTY



## 2010-14 Ford Mustang Sidemarker Installation Guide



Thank you for your purchase of this unique product for your Ford Mustang! With this plug-and-play LED Sidemarker, you will be able to upgrade your factory sidemarker to a brighter, more modern appearance on the road. This product is a direct replacement for your factory sidemarker.

**Tools Needed:** 7mm and 10mm socket wrenches, Philips screwdriver, non-marring tool (optional)

PLUG  
PLAY



## Rear Sidemarker Installation



1. If you have a non-marring tool, you may be able to remove the sidemarker by inserting the tool in the backside of the sidemarker and pushing forward toward the front of the vehicle. You may then proceed to step 5.



2. If you do not have a non-marring tool or are unable to remove the sidemarker, remove the three screws in the wheel well, using a small Philips screwdriver, or socket with bit.

*See inside for further instructions.*

## Rear Sidemarker Installation (cont.)



**3.** Pull back on the rear bumper, unclipping to access sidemarker.



**4.** Remove the sidemarker by pressing on the clip towards the front of the vehicle, then pushing it out.



**5.** Twist the factory plug counter clockwise to remove from the sidemarker, and remove the bulb.



**6.** Plug the connector from your new sidemarker into the socket. Ensure you have the correct polarity by hitting the unlock button. If the sidemarker doesn't illuminate, flip the connector 180°.



**7.** Twist the plug back into the new sidemarker to seal.



**8.** Place the sidemarker back into the bumper, clipping it into place.



**9.** Clip the bumper back into position, and reinstall the screws. Repeat for other side.

## Front Sidemarker Installation



**1.** Using a 7mm socket wrench, remove the three screws in the wheel well.



**2.** Pull back the wheel well from bumper, just enough to access the sidemarker.



**3.** Using a 10mm socket wrench, remove the two nuts on the back of the sidemarker.



**4.** Push the sidemarker out from the bumper.



**5.** Twist the factory plug counter clockwise to remove from the sidemarker, and remove the bulb.



**6.** Plug the connector from your new sidemarker into the socket. Ensure you have the correct polarity by hitting the unlock button. If the sidemarker doesn't illuminate, flip the connector 180°.

*See back for further instructions.*