

DIODE DYNAMICS

PERFORMANCE LIGHTING TECHNOLOGY

2015+ Ford Mustang Sidemarker Installation Guide



Thank you for your purchase of this unique product for your Ford Mustang! With this plug-and-play LED Sidemarker, you will be able to upgrade your factory sidemarker to a brighter, more modern appearance on the road. This product is a direct replacement for your factory sidemarker.



1. Remove the factory sidemarker by reaching behind and depressing the tab on the side closest to the wheel well. Once the tab is unclipped, slide the sidemarker towards the wheel well to pull the sidemarker housing out.



2. Looking at the factory sidemarker housing, depress the clip to remove the sidemarker and bulb socket completely. Set the factory sidemarker aside. It will not be reused.

See back for further instructions.



2015+ Ford Mustang Sidemarker Installation Guide



3. Install your new Diode Dynamics LED Sidemarkers by plugging the sidemarker into the factory wiring harness.



4. Finish your installation by sliding and clipping your new LED sidemarker into place

Please contact **Diode Dynamics** should you have any questions about the installation or wiring process, at **314-205-3033** (10a-5p CST) or **contact@diodedynamics.com**.

NEED MORE HELP?

Scan the QR code to link to our installation video online!

We've taken the time to test our products on your vehicle. We can guarantee compatibility and fitment the first time - no guessing game! If you need more help with installation, watch our step-by-step video to walk you through the process.

You 



This installation guide is for the following SKU:

DD5002 Mustang 2015 LED Sidemarker Clear (set)
DD5003 Mustang 2015 LED Sidemarker Red (set)
DD5004 Mustang 2015 LED Sidemarker Smoked (set)

**100% SATISFACTION
GUARANTEE**

**3 YEAR
WARRANTY**

