

DIODE DYNAMICS

PERFORMANCE LIGHTING TECHNOLOGY

2015+ Ford Mustang Sidemarker (EU/AU) Installation Guide



1. To begin, using the included t-taps, tap the pink connectors on the included wiring harness to any +/- signal wire that will switch on when the tail lights are on. We recommend tapping the license plate wires to accomplish this. Once that is complete, run one connector to the sidemarker location on each side of the vehicle.



2. Next, remove the factory sidemarker by reaching behind and depressing the tab on the side closest to the wheel well. Once the tab is unclipped, slide the sidemarker towards the wheel well to pull the sidemarker housing out. Set the factory sidemarker aside. It will not be reused.



3. Install your new Diode Dynamics LED sidemarkers by plugging the sidemarker into the wiring harness.



4. Finish your installation by sliding and clipping your new LED sidemarker into place. Be sure to tuck all wiring away from any heat element, including the exhaust.

This installation guide is for the following SKU:

DD5071 Mustang 2015 EU LED Sidemarker Clear (set)
DD5073 Mustang 2015 EU LED Sidemarker Smoked (set)

DD5072 Mustang 2015 EU LED Sidemarker Red (set)

