

SS5 CrossLink Universal Bracket Kit

Thank you for your purchase of our new SS5 CrossLink Universal Bracket Kit. This universal bracket kit is used to mount your Stage Series CrossLink Lightbar to your vehicle. Basic installation instructions are included below.



Please contact us if you have any questions.

Tools Needed: 10mm socket, drill, 5mm drill bit, 10mm wrench

1. Drill two 5mm holes for each bracket, four holes total.
2. Using a 10mm socket and wrench, secure the brackets onto the vehicle. Use the included 20mm M6 flange bolts and M6 flange nuts to secure the bracket.
3. Assemble and wire your lightbar using the included CrossLink lightbar instructions.

Please contact **Diode Dynamics** should you have any questions about the installation or wiring process, at **314-205-3033** (10a-5p CST) or **contact@diodedynamics.com**.

This installation guide is for the following SKU: DD7216 SS5 CrossLink Universal Bracket Kit