

## SS<sub>3</sub> FOGLIGHT KIT BUILDING GUIDE



Use this information to build your own SS3 Fog Light Kits. By stocking both pods and mounting kits, you can supply a variety of customers while carrying lower total inventory. **Please contact your account manager with any questions.**



KIT NAME	POD TYPE	MOUNTING KIT	FITMENTS*	NOTE
Type AS	SS3 Standard	A	Ford	
Type CH		CH	Chevy, GMC	
Type F2		F2	New Ford Truck	
Type FT		FT	Older Ford Truck	
Type GM		GM	Chevy, GMC	
Type GM5		GM5	GMC Sierra	
Type OB		OB	Subaru Outback	
Type SD		SD	Ford Super Duty	
Type SDX		SDX	Ford Super Duty	
Type SV1		SV1	Chevy Silverado	
Type SV2		SV2	Chevy Silverado	
Type X		X	Subaru WRX	
Ram Horizontal		Ram Horizontal	Ram Truck	
Ram Vertical		Ram Vertical	Ram Truck	
Type A	SS3 Round	A	Subaru, Ford	
Type M		M	Jeep	
Type MR		M AND MR	Jeep	<i>Requires both M and MR brackets.</i>
Type MS		MS	Jeep	
Type B	SS3 Angled	B	Toyota, Lexus	
Type CGX		CGX	Lexus	
Type FBS	SSC1 Standard	FBS	Ford Bronco Sport	

\*See detailed fitment list on website.