

DIODE DYNAMICS

RGBW CONTROLLER

24-KEY RF

FEATURES

- ▶ Control RGBW products, with True White selection
- ▶ Simple to use, with saved color presets
- ▶ Four preset patterns
- ▶ Fully waterproof, with new M8 style connectors
- ▶ Output up to 8 amps (2A per connection)



INSTALLATION

- ▶ Connect the controller to a 12V power source and ground (e.g., the battery). Then connect your RGBW driver to the controller.
- ▶ If your controller isn't working properly, ensure that there is a reliable 12V connection to the DT input. You may also test the controller function by carefully touching the leads to the battery. Lastly, ensure that the battery is installed properly in the remote.